

Long pants are required at all times when operating this equipment.

Job/Task Step	Hazard	Hazard Control Method/PPE
Inspect Equipment/PPE Check/Buddy System	N/A	<ul style="list-style-type: none"> • Don all required PPE for use of the Battery Drill. Approved Safety Glasses with side shields, Long Pants, Closed Toe Shoes, and Ear Plugs. • Additional foot protection is required when working with heavy parts and pieces. • Tuck in shirt, not loose fitting clothing or jewelry. • Long hair must be pulled back or tucked into a hat. • Work with the supervisor of the space to review operation and ensure all risks have been addressed.
Insert Bit/Drive and ensure that it is tight	Abrasion/Laceration	<ul style="list-style-type: none"> • Handle the bit/driver carefully and be aware of sharp edges. • Use chuck/key. • Be aware of pinch point hazards. • Wear gloves
Drill Hole/Tighten Screw	Abrasion/Laceration, Eye Injury, Muscle Strain, Noise Hazards	<ul style="list-style-type: none"> • Be aware of pinch points and moving parts. Loose clothing, jewelry and hair can be caught in moving parts. • Wear approved safety glasses with side shields to protect from flying debris. • Use proper technique when bending/pushing. • Wear ear plugs to protect from high noise. • Wear all required PPE; Safety Glasses, Ear Plugs, Gloves, Close Toe Shoes, and Long Pants.
Remove Bit/Drive	Abrasion/Laceration	<ul style="list-style-type: none"> • Handle the bit/driver carefully and be aware of sharp edges. • Use chuck/key.

		<ul style="list-style-type: none">• Be aware of pinch point hazards.• Wear gloves
Clean the Area	Flying Debris, Abrasion/Laceration, Muscle Strain	<ul style="list-style-type: none">• Sweep up of all debris from drilling/screwing activities.• Be aware of sharp objects.• Use proper lifting technique when cleaning.• Wear safety glasses and gloves.

